






ROBOGUARD







Wireless Outdoor Beams

MAIN ITEMS





Picture	Code	Item	Description	Recommended Retail
	ROB001 ROB001G ROB001W	Roboguard Wireless Outdoor Beam with mounting bracket	The roboguard is a stand alone, wireless automatic outdoor intruder security system using passive infrared sensor beams that detect movement up to 20 meters away in an 110° arc.	R 2 284,62
	HQ001	Mobile HQ Unit	A portable 8 zone, 4 output, base-station used to receive and annunciation signals from up to 8 Roboguard Sensors.	R 1 295,82
	ROB016	Alarm Interface	The Roboguard Alarm Interface can, supervise and monitor up to four Roboguards, with individual intruder detected, tamper and status LED's.	R 870,33
	DP002	Roboguard Keypad	A 4 zone, 4 output, fixed Roboguard base station used to interface Roboguards into an existing alarm panel.	R 440,62
	TRX003	Roboguard Universal Receiver uRx	A separate receiver that provides the data stream for the Keypad and for the repeater station.	R 350,55
	TRX002	Roboguard Universal Transmitter uTx	A Roboguard Transmitter capable of transmitting roboguard intruder and roboguard remote alarms after triggering from externally connected systems.	R 489,56
	TRX005	Roboguard 4 Button Remote Transmitter	A handheld remote transmitter used as a panic button and remote control for radio base-stations.	R 205,49
	TRX006	Roboguard 6 Button Remote Transmitter	A handheld remote transmitter used as a panic button and remote control for radio base-stations.	R 253,85
	ROBP7B/W	Roboguard 7Amp/Battery Power Pack	The Power supply and relay board can be used to connect the HQ to external equipment such as a siren and/or alarm panel. Available in Black or White.	R 1 013,19
	TRX004	Roboguard LED Driver	The LED unit is used to visually indicate the status of the Roboguard system to a distant user.	R 289,71
	ROB007B	Roboguard Ball Type Mounting Bracket	The bracket can be mounted to any surface and allows the installer to swivel the Roboguard and aim the beams in the required direction.	R 157,03

SPARES

Picture	Code	Item	Description	Retail
	ROB005	Roboguard Battery	1.5Volt "c"-Size Alkaline battery - Kinetic	R 30,33

	ROBHQBP	HQ Battery	6Volt 1000mAh Battery - Kinetix	R 141,43
	ROBHAR01	Internal wiring harness	Wiring between TX PIR and CPU PIR	R 145,05
	ROB002	CPU PIR	Bottom PIR for processing signals	R 877,58
	ROB003	TX PIR	Top PIR for transmitting signals	R 749,45
	ROB008	Inner Lense	Inner Polo IP6 Fresnel lens	R 48,97
	ROB009	Outer Lens	Outer UV resistand lens	R 48,97

ACCESSORIES

Picture	Code	Item	Description	Retail
	ROB017	Snitch	Informs and triggers a buzzer when a Jamming signal is present for a set time duration.	R 350,55
	LED014	Armed Status LED	Outdoor Led to supply status of system. Armed/Disarmed or Alarm	R 120,00
	NB527	Siren	10 to 15 Watt Siren	R 53,00
	ROBOTEXT	Robotext GSM	A GSM designed to SMS the status and alarm triggers	R 1 866,57



ELECTRIC FENCE AND SECURITY CENTRES

SECURITY SYSTEMS

0861 STAFIX / www.roboguard.co.za

All prices excludes VAT